



# R1510L 14V ELECTRONIC ALTERNATOR CONTROLLER /VOLTAGE REGULATOR



### Features:

- Voltage Regulation, Pulse Width Modulated
- Field-to-Ground Fault Protection (GFP)
- Trouble-Shooting Light (TSL)

### Benefits:

- \* Increased Regulator life. Reduced panel lights flicker
- \* Protects against grounded alternator field
- \* Identifies grounded field. Reduce trouble-shooting time.

**Voltage Regulation: 14.2V ± 0.2V. Max Field Current: 5A. Field-to-Ground Protection @ Field current > 6A**

### VOLTAGE REGULATION


The Voltage Regulator keeps the bus voltage constant by controlling the alternator's field current: increasing it when the system load increases and decreasing it when the load drops..

### FIELD TO GROUND SHORT PROTECTION


Should the alternator's field become shorted to ground (the reason most Voltage Regulators fail), the field-to-ground short protector will deactivate the Voltage Regulator, and switch on the unit's RED field-to-ground short indicator.

TROUBLESHOOTING LIGHT (TSL). The troubleshooting light on the unit is designed to alert the user to the condition of the Alternator / ACU system. **The light is normally off.**

**RED LIGHT, TSL,** with master switch on indicates a ground short in the alternator field or controller to field wiring.



Wiring Diagram



Mounting Diagram

Height: 1.10"

The R1510L replaces

- PIPER: 450-392; 484-121; 68804-03; 756-055
- BEECH: 169-380063
- WICO: X16300B; X17990; X18150
- ELECTRODELTA: VR200; A
- PFT/LAMAR: B00267-1,-2; B00331-1, -2
- COMMANDER: 1816110
- PRESTOLITE: FVR4004, 4224
- RBM: 87-87102-21
- LYCOMING: LW-11357, LW-12747

**Consider upgrading** to the R15V0L Alternator Controller. The R15V0L combines the R1510L with Over Voltage Protector and Dual Color Trouble-Shooting light.



# R1510L

## 14V ELECTRONIC ALTERNATOR CONTROLLER /VOLTAGE REGULATOR

### HOW THE SYSTEM WORKS

Turning on the master switch applies battery voltage to the input of the R1510L or alternator controller/regulator through the Over-Voltage Relay (OVR).

The current passing through the voltage regulator is applied to the field of the alternator. Without the engine running, the field voltage is typically 0.5-2V less than the bus or battery voltage.

#### Voltage Regulation

When the engine is running, the voltage regulator keeps the bus voltage constant by controlling the alternator's field current: increasing it when the system load increases and decreasing it when the load drops. The regulated bus voltage is normally about 14V unless the alternator is self-current limiting<sup>1</sup> or if there is a voltage drop across the alternator field circuit breaker, alternator switch, OV Relay<sup>2</sup>, or wiring and connections between the bus and the red wire on the control unit/voltage regulator. Voltage drops across the different components and connections occur when current, up-to 4 Amps in some instances, passes through the resistance built-up in them. *The resistance build-up causes flickering ammeter and instrument panel lights.*

#### Field-to-Ground Short Protection

Should the alternator's field become shorted to ground (*the reason most Voltage Regulators fail*), the field-to-ground short protector will deactivate the Voltage Regulator, and switch on the unit's RED TSL.

**Trouble-Shooting Light (TSL).** The TSL on the unit is designed to alert the user to the condition of the Alternator / ACU system. The light is normally off.

**RED LIGHT, TSL,** with master switch on indicates a ground short in the alternator field or controller to field wiring.

<sup>1</sup> self-current limiting—Internal characteristics of the alternator that causes it to limit its current and voltage output at a given speed.

<sup>2</sup> OV Relay—Over Voltage Protection Relay opens its normally closed contacts when the buss voltage exceeds 16V or the OV trip point.

### INSTALLATION INSTRUCTION


- 1 Disconnect and remove the present ACU/VR.
- 2 At the ACU/VR, measure the alternator's field resistance: i.e. resistance between the field and the ground wire. A resistance of 3.5 to 6Ω is normal. If the measured resistance is outside the specified range, check the alternator field and the connections/wire from the alternator's field wire (at the ACU/Regulator) to ground. 0Ω indicates a field to ground short. Correct fault.
- 3 Mount and connect the new ACU to the system.
- 4 Perform the Post Installation Test Procedure.

### POST INSTALLATION TEST PROCEDURE

1. Turn on the Master switch and observe: On the ACU the TSL light is off. If the light is Red, the Field or field wire is shorted to ground.
2. Measure the voltage on Red and Blue wires. The Red should read Battery voltage, while the Blue reads 1-2 volts less than the Red wire.
3. If the steps 1 and 2 are successful, perform step 4.
4. Turn Off all the avionics. Start the engine. At 1500-1600 RPM measure bus voltage: It should read 13.8V - 14.4V. If the bus voltage exceed these limits, check for voltage drop in the 5A breaker, the Alt switch, and pre-ACU/VR wires.

### TROUBLE-SHOOTING THE SYSTEM

See the Trouble-Shooting Notes (TSN) page and or TECHCARDS for information on how to solve problems in the system.



Wiring Diagram



## **TROUBLE-SHOOTING THE SYSTEM**

### **14V Type B alternator system on Piper, Beech, etc R1510L or other ACU/regulator**

When the master switch (ALT & BAT) are turned on, battery voltage is applied to the Bus & OV Relay input.

Take all voltage measurements at test points (TP) A, B, D, E and F referenced to ground.

|                 |                 |
|-----------------|-----------------|
| A. _____ Volts. | B. _____ Volts  |
| D. _____ Volts. | E. _____ Volts  |
| F. _____ Volts. | F1. _____ Volts |

The voltages measured at A, B, D, and E should be the same, Bus voltage (around 12V). The voltage on F (field or alternator controller/voltage regulator output) will be 0.5 to 2V less than the voltage at A, B, D, or E. The voltage at F1 will be the same as F.

*If the voltage at A is 0.2V more than that on E, check the 5 Amp breaker, ALT switch, and connections between the bus and E for high resistance or open circuit. A high resistance between A & E may lead to [flickering / oscillating ammeter and panel lights](#). An open circuit between A & E will not allow current to get to the controller/regulator and subsequently no current to the alternator's field and [no voltage regulation](#). When there is no voltage regulation, the [Bus voltage remains at battery voltage \(about 12V\)](#).*

*If the voltage on F1 is 0.2V or more less than the voltage F, check for poor connection or open circuit between the controller/regulator output and F1 on the alternator. If the resistance between the F and F1 is higher than 1Ω, the alternator may not carry its rated load, showing a symptom similar one where there is an open stator wire or open diode in the alternator.*

*If the voltage on F1 is 0V or close, check for a ground short on F1 on the alternator or wire from F on the controller/regulator.*

*If there is a field-to-ground short, the R1510L will turn itself off and turn its [built-in Trouble-Shooting Light \(TSL\) Red](#).*

*An open stator wire or open diode in the alternator will make the [alternator only able to carry about half its rated output](#). For example, a 70A 12V alternator has a 14V output with about 30A load on it. When the load is increased to 40A, the bus voltage drops to 12 to 13V, indicating an alternator that is current limiting.*

See [TECHCARD](#) for resistance and voltage measure-

With the engine off, when the master switch (ALT & BAT) is turned on, battery voltage (12V) is applied to the input of the ACU/regulator through the 5 Amp FLD circuit breaker, ALT switch and the OV Relay. The applied voltage causes current to flow to the alternator's field through the ACU/regulator to excite the alternator's field.

With the engine on and the master field switch on, the ACU/regulator controls the excitation of the alternator to produce a Bus voltage of 13.8 –14.3V. This regulated voltage charges the battery and allows the alternator to power all the electrical system loads in the aircraft.


The 5 Amp circuit breaker opens if the current going to the ALT field exceeds 5 amps, beyond a time lag, to protect the wires from the Bus to the field. *Some wrongly expect the breaker to protect their non-Zeftronics regulator.*

If the Bus voltage exceeds the preset over-voltage (OV) limit, the OV normally closed Relay, will open up and disconnect the Bus from the ACU/regulator to remove excitation from the alternator's field.

When power is applied to a static (non-rotating) alternator through the ACU/regulator, the F1 voltage is 0.5-2V less than Bus voltage. When the alternator is rotating, F1 voltage will start low and increase with each load increase until the alternator current limits.

See [TECHCARD](#) for resistance and voltage measurements.

Wiring Diagram



In this **Type B** system: the ACU/Regulator is between the BUS and the Alt field. To control the bus voltage, the unit switches power to one side of the field several times a second. The OVR opens when OV occurs.



## Frequently Asked Questions & TECHCARD Notes

### 14V Type B alternator system on Piper, Beech, etc

### **TROUBLE-SHOOTING THE SYSTEM**

#### [Flickering / oscillating ammeter and panel lights.](#)

Check the 5 Amp breaker, ALT switch, OV Relay and connections between the bus and the OV Relay's output for high resistance or intermittent connection.

#### [No voltage regulation](#)

With the master switch on and Battery voltage measured on the OV Relay output,

- Look for Bus voltage on the ACU/Regulator input and out put.
  - If there is no Bus voltage on the ACU input, look for a broken wire between the ACU and the OVR.
  - If the input voltage is more than 0.2V lower than the bus voltage, look for & correct the device (5A breaker, ALT switch, OVR or connection or wire) that is causing it.
  - If the output voltage is 0V and the input has battery voltage, look for a grounded alternator field or field wire. If the field resistance is correct as shown in step 5 of the installation tests and the ACU's [Trouble-Shooting Light](#) (TSL) is off, send the ACU/Regulator in for test/repair.
  - If the TSL is Red, repair the field ground fault or replace the alternator.
  - If the output voltage is the same as the input voltage, look for an open alternator field or field wire. If the field resistance is higher than what is shown in step 5 of the installation tests, send the alternator in for test/repair. If the field resistance is correct, send the ACU in for test/repair.

#### [Bus voltage remains at battery voltage \(about 12V\)](#)

To solve this problem, see [No voltage regulation](#).

#### [Alternator carries only about half its rated output.](#)

Look for an open stator wire or open diode in the alternator. In Piper PA 28 & 32 series, check the condition of the diode between the bus and alternator output. Check the shunts and alternator output wires, indicating an alternator that is current limiting.

#### [Bus voltage drops with load increase](#)

To solve this problem, see [Alternator carries only about half its rated output](#).

OUR GOAL IS TO HELP YOUR SYSTEM OPERATE BETTER  
AND HELP YOU UNDERSTAND ITS OPERATION.

ZEFTRONICS  
TECHCARDS

INSTALLATION TESTS. BEFORE INSTALLING THIS UNIT, PERFORM TESTS:


1. Read pages 1 to 3 and this page.
2. Check for and replace open, frayed, or broken wires. Clean thoroughly or replace corroded, dirty, or oxidized connections, terminals, contact, or poorly soldered wire junction.
3. Check for Open or Ground-shortened alternator field. Most 12V alternators have 3-6Ω field resistance. Ground shorted alternator field will damage most Voltage Regulators/ACU. **If the alternator has a field to ground short, do not connect the ACU/Regulator to it.**
4. With the engine off: Check voltage drops across the field and Alt circuit breakers, and OV relay. High voltage-drop means excessive junction resistance and will lead to many problems like: fluctuation ammeters, charge-meters and panel lights.
6. Perform and record the following tests with the **Master Switch Off**:
- |                            | 12V Values | Typical Values |
|----------------------------|------------|----------------|
| A. Field resistance at ALT | _____ Ω    | 3 – 6Ω         |
| B. Field resistance at ACU | _____ Ω    | 3 – 6Ω         |
| C. Field SW resistance     | _____ Ω    | 0 – 0.1Ω       |
| D. Field C/BKR resistance  | _____ Ω    | 0 – 0.05Ω      |
| E. ALT C/BKR resistance    | _____ Ω    | 0 – 0.05Ω      |
6. Perform and record the following tests with the **Master Switch On**:
- |                        | 12V Values | Typical Values |
|------------------------|------------|----------------|
| F. BUS Volt Engine Off | _____ V    | 12 – 13V       |
| G. ACU/Reg input Volt  | _____ V    | 12 – 13V       |
| H. Field Voltage       | _____ V    | 0.5-2V <VBus   |
7. **Post Installation.** If all tests are correct to or per steps 5 & 6, run the engine and record:
- |                | 12V System | Typical value |
|----------------|------------|---------------|
| I. Bus voltage | _____ V    | 13.8 – 14.3V  |

For tech help & other TechCards, call: **903-758-6661**

©ZEFTRONICS, 2002

**ZEFTRONICS**  
Electrical Charging System Solutions

#### [Wiring Diagram](#) Type B Alternator Control System



In this **Type B** system: the ACU/Regulator is between the BUS and the Alt field. To control the bus voltage, the unit switches power to one side of the field several times a second. The OVR opens when OV occurs.