



# R25V0N ALTERNATOR CONTROLLER: VREG, OV RELAY, LOW-OV WARNING FOR TYPE A 28V ALTERNATOR SYSTEMS

### Features:

- Voltage Regulation, IC Sense Referenced
- Over Voltage (OV) Protection
- Low Voltage & OV Sensor & Light Output
- Field Controller Generates Low Heat
- Externally Adjustable Voltage Regulation
- Light Weight and Repairable

### Benefits:

- \* Increase Regulator Life. Not Temperature Sensitive
- \* Protects System Against Overexcited Alternator Field
- \* Warns of Low & OV Conditions
- \* Increase Regulator Life
- \* Increased Ease of Ownership
- \* Reduced Long-term Ownership Cost

Voltage Regulation: 28.4V ± 0.4V. Max Field Current: 7A.

### VOLTAGE REGULATION

Using the voltage sensed from the OV Relay output, the Regulator keeps the bus voltage constant by controlling the alternator's field current: increasing it when the system load increases and decreasing it when the load drops. The Regulator controls the field by grounding or opening the one side of the field connected to pin F.



The R25V0N works in the one alternator (single engine) application as well as in the dual alternator (single or dual engine application). It is the best replacement for the Prestolite VSF7403 type Voltage Regulator.

### OVER VOLTAGE (OV) PROTECTION (NOT IN THE UNIT)



The external OV Protector (OVP) or OV Relay deactivates the Voltage Regulator by removing power to its input and one side of the field if the bus voltage exceeds 32V. This removes the alternator field excitation and thus protect sensitive avionics equipment and the battery.

### TYPE A VOLTAGE REGULATION:

This controller has a "Type A" regulator which excites the field of the alternator by providing controlled ground to one side of the alternator field (F2), with the other side (F1) powered by the OVR output.

The R25V0N replaces

- PRESTOLITE: VSF7403,2,1,4 & OV RELAY
- ELECTRODELTA: VSF7403A & OS75-28
- TCM: 649684-2, 649440-2 & OV RELAY
- LYCOMING: LW101079, 77347 & OV RELAY
- PIPER: 550-581 & OV RELAY





## R25V0N ALTERNATOR CONTROLLER FOR TYPE A 28V ALTERNATOR SYSTEMS

### HOW THE SYSTEM WORKS:

REFER TO FIGURE 1 & 2 PAGES 1 & 3

Turning on the master switch applies battery voltage to the input of the Alternator Controller or Voltage Regulator (VR) through the Over-Voltage Relay (OVR).


In this "Type A" charging system configuration, the VR applies controlled grounding to one side of the alternator's field while the other side has power on it from the OVR. Without the engine running, the field voltage is typically 0-2V. With the engine running, the field voltage is 27-0.5V while the bus voltage is at 28V. *The field voltage starts out high and decreases with increased system load.* If the field voltage becomes 0, the system will experience an OV condition, and the OV Relay will open to turn off the VR thereby removing excitation from the alternator's field.

### Over Voltage Protection

The OV Relay is a normally closed switch which opens when the bus voltage exceeds 32V. It has a time delay that prevents nuisance tripping caused by system noise or voltage spikes.

The regulated bus voltage is normally about 28V unless the alternator is self-current limiting<sup>1</sup> or if there is voltage drop in the alternator field circuit breaker, alternator switch, OV Relay, or wiring and connections between the bus and the red wire on the VR. These voltage drops across the different components and connections occur when current, up-to 3 Amps in some instances, passes through the resistance built-up in them. *The resistance build-up causes flickering ammeter and instrument panel lights.*

<sup>1</sup> self-current limiting—Internal characteristics of the alternator that causes it to limit its current and voltage output at a given speed.



### INSTALLATION INSTRUCTION

1. Disconnect and remove the present ACU/VR.
2. At the ACU/VR, measure the alternator's field resistance: i.e. resistance between the F1 (I) and F2 (F). A resistance of 10 to 18Ω is normal. If the measured resistance is outside the specified range, check the alternator field and the connections/wire from the alternator's field wire (at the ACU/VR) to field wire to the OVR output wire. 0Ω indicates a field to ground short. Correct fault found.
3. Verify that the input (Alt Switch, Field breaker, etc) resistance to the OVR is below 0.1Ω. Correct faults found.
4. Mount the ACU/VR and connect the OVR and ACU/VR to the system.
5. Perform the Post Installation Test Procedure.

### POST INSTALLATION TEST PROCEDURE

1. Turn on the Master switch and measure
  - Bus voltage \_\_\_\_\_ V. \_\_\_\_\_ V.
  - I voltage \_\_\_\_\_ V. \_\_\_\_\_ V.
  - F1 voltage \_\_\_\_\_ V. \_\_\_\_\_ V.
  - F2 voltage \_\_\_\_\_ V. \_\_\_\_\_ V.
  - W voltage \_\_\_\_\_ V. \_\_\_\_\_ V.

The inputs should read bus voltage. VR output voltage on the "type A" should read 0-2V.

2. If the step 1 is successful, perform step 3.
3. Turn Off all the avionics. Start the engine. At 1500-1600 RPM measure bus voltage: It should read 27.5V - 28.5V. If the bus voltage exceed these limits, check for voltage drop in the 5A breaker, the Alt switch, and pre-ACU/VR wires.

### TROUBLE-SHOOTING THE SYSTEM

See the Trouble-Shooting Notes (TSN) page and or TECHCARDS for information on how to solve problems in the system.

### WIRING DIAGRAMS

See pages 1 and 3 for wiring diagrams of the dual alternator system.



# TROUBLE-SHOOTING THE SYSTEM WITH R25V0N

## 24V Type A alternator system on Beech, Cessna, Piper, Twin Commander etc

### TROUBLE-SHOOTING

1. With BAT, ALT, REG & FLD switches on and the engine off, the voltage on pin I of the R2510N will be the same as the bus voltage. If it is more than 0.2V less, look for high resistance in the 5-10A breaker, the Alt switch, the OV Relay, the Reg selector switch, or connections at any of those devices). None of the devices should have a voltage drop that is higher than 0.1V.
2. Turn Off all the avionics. Start the engine, and at 1500 RPM measure a bus voltage of 27.5-28.5V. If the bus voltage exceed these limits, verify the voltage adjustment on the controller and the voltage drops of the power input devices.  
At that speed, depending on the system load, the voltage on the field will decrease from about 27V to 0.5V. Loading the alternator beyond its rating (for a given speed) will cause it to self current limit. Current limit is indicated by a drop in bus voltage which occurs as system load current exceeds a certain point.

#### One or Both Alternators Drop Off-line

Make sure that the 5-10A breaker is okay. Then check the condition of the Alt switch, the OV Relay, and Reg switch. Verify that the voltage on pin I is the same as the bus voltage.

**Check one unit at a time.** On the R25V0N, if there is no voltage on pin F1, the OVR may have tripped due to a grounded ALT field or field wire. At the R25V0N and at the alternator's field, check the field resistance: it is normally 10 to 18Ω. If the resistance is out of range, check the ALT field or wires/connections/switches/fuses from the regulator to the field. An alternator with a grounded field/field wire will cause an OV fault. Test the system again with only one alternator field switch on at a time.

#### Fluctuating Charge-meter / Flickering Panel Lights

This problem is usually caused by a resistance build-up in the ALT switch or OV Relay, the 5Amp breaker, or bad wires/connections between the Bus and the Red wire on the Regulator.

With the master switch On, verify that the voltage drop across the alternator switch and 5-10Amp circuit breaker is less than 0.2V. Another way to do it is to verify that the Alt switch & OV Relay resistance is 0.1Ω or less. If either measurement is higher than indicated, replace the bad part.





Figure 2. TYPICAL WIRING DIAGRAM  
DUAL ALTERNATOR SYSTEM

### TROUBLE-SHOOTING

Checking the condition of the voltage regulator/controller & OVR

1. With the Bat & Alt switches on, engine off, measure the voltages at the indicated (refer to the wiring diagram).

**Single Alt /figure 1.** BUS: \_\_\_\_\_ 5A Bkr: \_\_\_\_\_ I PWR: \_\_\_\_\_

F1: \_\_\_\_\_ F2: \_\_\_\_\_ W: \_\_\_\_\_ R Fld: \_\_\_\_\_ R Fld: \_\_\_\_\_

**Dual Alt /figure 2.**

**Main Reg Selected.** BUS: \_\_\_\_\_ 5A Bkr: \_\_\_\_\_ I PWR: \_\_\_\_\_

F1: \_\_\_\_\_ F2: \_\_\_\_\_ W: \_\_\_\_\_ R Fld: \_\_\_\_\_ R Fld: \_\_\_\_\_

**Aux Reg Selected.** BUS: \_\_\_\_\_ 5A Bkr: \_\_\_\_\_ I PWR: \_\_\_\_\_

F1: \_\_\_\_\_ F2: \_\_\_\_\_ W: \_\_\_\_\_ R Fld: \_\_\_\_\_ R Fld: \_\_\_\_\_

Checking the condition of the alternator Field & Power input devices

2. Disconnect pin F1 & F2 on the controller. Measure the resistances indicated below:

F2 to F1 ALT \_\_\_\_\_ Ω. Pin I to BUS \_\_\_\_\_ Ω. F2 to F1 ACU \_\_\_\_\_ Ω

The field resistance is normally 10 to 18Ω. If the resistance is out of that range, check the alternator field or wires/connections/switches/fuses.

The resistance from pin I to bus should be 0-0.1Ω. A higher resistance may lead to fluctuating ammeter or panel lights or erratic bus voltage.

